

## **How to Affix the Seventh-day Adventist Memorial Medallion**

It is recommended that families arrange to have the cemetery management or funeral home to affix the medallion to the deceased's headstone/grave marker.

### **DIY instructions if you decide to affix the medallion yourself:**

Before you place the medallion on the headstone/grave marker, speak to the cemetery management about your plans; they may affix it for you. If you decide to affix it yourself, you will need several items:

- A clean rag to clean the portion of the headstone/ grave marker where the medallion will be affixed.
- All-purpose spray cleaner.
- Stiff scrub brush.
- Epoxy. We recommend the Bonstone 1 oz. Last Patch Gel Kit. Available from Bonstone Materials Corporation at 262.363.9877 or [bonstone.com](http://bonstone.com)
- A tool to apply the epoxy to the medallion.

1. First, make sure the area where you will affix the medallion is clean and dry. Read the instructions on the epoxy and prepare the epoxy according to instructions.

2. When the epoxy is ready, apply it to the back of the medallion. Do not get epoxy closer than .25 inches from the edge of the medallion, so that the adhesive does not ooze out around the medallion when you place it on the marker.

3. Make sure the medallion is straight, firmly press it against the headstone/grave marker, and hold for 4 to 5 minutes to make sure it stays in place.

If you require assistance with the installation of the medallion, the cemetery staff or a local monument company may be hired to install it for you.